

Instructions to Set up Programmable Dimmers

To operate the dimmer in manual mode

Adjust light output % with manual mode

1. Click **FUNC**, use ↑↓ to navigate options to Set Brightness and click **SET**
2. Use ↑↓ to select % and click **SET**
3. Repeat step 1 & 2 to manually make adjustments

To set up the dimmer to run in programmable mode

1. Set up the clock
2. Set up schedules with time frames and correlated light output percentage
3. Review the schedules to make sure whole 24 hours light output is set up properly
4. Turn on Program Schedule
5. When the green light blink on PROG., it is running on the program mode.

Set Clock

1. Click **FUNC**, use ↑↓ to Set Clock and click **SET**
2. Use ↑↓ to adjust time to current time and click **SET**

Set up Program Schedules in 24 hours cycle

1. Click **FUNC**. then use ↑↓ to navigate options to Set Program click **SET**
2. Use ↑↓ to navigate options to Schedule Setting then click **SET**
3. Use ↑↓ to select % and correlated time frame to complete 24 hours cycle

Turn on Program

1. Click **FUNC**. ↑↓ to Function Menu Set Program click **SET**
2. Use ↑↓ to navigate options to Program Schedule ON/OFF, click **SET**, Schedule ON click **SET**
3. When the program indicator light starts to blink, the program is set and on